



PROGRAMMING ACDC WIRELESS PUSH BUTTON

The wireless push button transmitter has to be programmed into a compatible radio receiver. No operation is possible until this operation has been carried out.

Press the LEARN button on the device radio receiver.

The LED will turn ON indicating that the receiver is in programming capture mode.

Now press the push button required twice.

The Led will now flash meaning the code has been accepted.

Before mounting the Wireless push button ensure that the controlled device is able to receive the transmission. The estimated range of the this unit is nominally 20 meters in open line of sight applications.

NOTE: *That metal structures and buildings can shield the transmission and influence range. Testing the LOCATION point of the transmitter before installation is important.*

The Wireless Push Button is for internal use only and is not to be mounted externally.

The push buttons is for up to 3 doors left middle and right.

